


Kit de refacciones para mantenimiento preventivo. / Kit of parts for preventive maintenance.

Rh-302
Birlo Contraacnasta
Against Basket Stud Bolt




Sh-036
Canasta y Buje Armado
Armed Basket and Bushing



Rh-306
Sello
Seal




Rh-309
Niple para Contra y Espaciador
Nipple for Spacer and Against




Rh-641
O´ring 2-018
2-018 O´ring



Rh-425
Cuerpo Contraacnasta
Basket Against Body




Rh-307
Rondana de Hule Contraacnasta
Rubber Washer Basket Against



Rh-419
Espaciador Contraacnasta
Spacer Basket Against




Rh-424
Contratuera Espaciador
Spacer Locknut



Rh-308
Empaque Contraacnasta
Basket Against Gasket



Rh-311
Tubo Union
Union Tube



Rh-423
Tuerca Union Tubo
Union Tube Nut

